


# How to distinguish the mode of modem

If “DISK” model, when connect to PC, the modem will be indicated as a CD-ROM in my computer, and the program will run and automatically.



## User Manual

If “**modem**” model, when connect insert to the PC, the modem will be indicated as a new hasrware asking for driver installation.

